


Pierro Silver 1 Group : (CE ETL)

ITEM: BOILER HYDRALIC CIRCUIT



ITEM NO.	Pierro Silver 1 Group : (CE ETL)
ITEM: BOILER HYDRALIC CIRCUIT	
A020015-00	BRASS CONNECTOR
A020017-01	BRASS CONNECTOR PT1/4*1/2-20UNF*1/2-20UNF
A020023-00	ANTI-EDDY VALVE BASE
A020024-00	SHAFT
A020025-00	BRASS NUT
A02004	BRASS PLUG
A02018	BRASS CONNECTOR 1/4"X1/8"
A02021	BRASS CONNECTOR 1/2-20UNF*PT1/4
A02022	ELBOW BRASS PT3/8*3/8
A02023	ELBOW BRASS 5/16*1/4
A02029B	LEVEL PROBE BASE
A02030A	PROBE FIXED BOLT
A02068	BRASS FITTING PS1/4*PS1/4*L42
A02069	BRASS FITTING PS1/4*PS1/4*L33.5
A04003	HEATING ELEMENT 2000W (CE)
A050010-00	SAFETY VALVE
A05008	PRESSURE RELEASE TAP BULK UNIT PS1/4xPS1/4
A05012	FLOWMETER DOSER
A05013A	S.C.N.R.DOSER VALVE 1/2*1/2*1/2
A05020A	SOL. VALVE WATER REFILL ASSEMBLY 208~240V 60Hz (ETL)
A08002	PROBE ( SUS304 /3mm L132 )
A10008	NUT M8
A10030	HEX SCREM (M10*16)
A170008-00	SI O-RING
A170009-00	TEFLON WASHER
A170011-01	SI-GASKET ELEMENT
A17002	NBR O RING
A180004-00	VALVE GASKET BRASS
A180005-00	VALVE GASKET BRASS
A23001	SPRING WASHER M8
A27002	PROBE FIXED SUPPORT
A28008	SPHERICAL BRONZE CONICAL FILTER
B050006-00	ANTI-EDDY VALVE V.A.R.
B05003A	FLOW METER GAUGE
B080001-00	BOILER
B10002	LEVEL PROBE ASSEMBLY
B300026-00	AUT.WATER REFILL TUBE REAR
B300028-00	HEAT EXCHANGER INLET TUBE

B300030-00	BOILER DRAINTUBE REAR
B300031-00	PRESSURE GAUGE COPPER TUBE
B300035-00	BOILER DRAIN TUBE FRONT
B300036-00	FLOWMETER INLET TUBE
B300038-00	EXPANSION DRAIN TUBE
B300057-00	HEAT EXCHANGER OUTLET TUBE
B300058-01	HEAT EXCHANGER RETURN TUBE
B300062-00	STEAM PRESSURE GAUGE TUBE
B300104-00	WATER LEVEL UPPER TUBE
B300108-00	AUT.WATER REFILL TUBE
B300242-00	STEAM OUTLET TUBE FRONT RIGHT
B300243-00	HOT WATER OUTLET TUBE REAR
B30215C	WATER LEVEL LOWER TUBE




ITEM NO.	Pierro Silver 2 Group : (CE ETL)
ITEM: BOILER HYDRALIC CIRCUIT	
A020015-00	BRASS CONNECTOR
A020017-01	BRASS CONNECTOR PT1/4*1/2-20UNF*1/2-20UNF
A020023-00	ANTI-EDDY VALVE BASE
A020024-00	SHAFT
A020025-00	BRASS NUT
A02018	BRASS CONNECTOR 1/4"X1/8"
A02021	BRASS CONNECTOR 1/2-20UNF*PT1/4
A02022	ELBOW BRASS PT3/8*3/8
A02023	ELBOW BRASS 5/16*1/4
A02029B	LEVEL PROBE BASE
A02030A	PROBE FIXED BOLT
A02068	BRASS FITTING PS/1/4*PS1/4*L42
A02069	BRASS FITTING PS/1/4*PS1/4*L33.5
A04005	HEATING ELEMENT 4000W (CE)
A050010-00	SAFETY VALVE
A05008	PRESSURE RELEASE TAP BULK UNIT PS1/4xPS1/4
A05012	FLOWMETER DOSER
A05013A	S.C.N.R.DOSER VALVE 1/2*1/2*1/2
A05020A	SOL. VALVE WATER REFILL ASSEMBLY 208~240V 60Hz (ETL)
A08002	PROBE ( SUS304 /3mm L132 )
A10008	NUT M8
A10030	HEX SCREM (M10*16)
A170008-00	SI O-RING
A170009-00	TEFLON WASHER
A170011-01	SI-GASKET ELEMENT
A17002	NBR O RING
A180004-00	VALVE GASKET BRASS
A180005-00	VALVE GASKET BRASS
A23001	SPRING WASHER M8
A27002	PROBE FIXED SUPPORT
A28008	SPHERICAL BRONZE CONICAL FILTER
B050006-00	ANTI-EDDY VALVE V.A.R.
B05003A	FLOW METER GAUGE
B080003-00	BOILER
B10002	LEVEL PROBE ASSEMBLY
B300109-00	AUT.WATER REFILL TUBE
B300138-00	WATER LEVEL UPPER TUBE
B300140-00	PRESSURE GAUGE COPPER TUBE

B30208C	FLOWMETER INLET TUBE
B30209C	HEAT EXCHANGER INLET TUBE
B30211A	BOILER DRAIN TUBE FRONT
B30212C	BOILER DRAINTUBE REAR
B30213C	AUT.WATER REFILL TUBE REAR
B30215C	WTAER LEVEL LOWER TUBE
B30219C	EXPANSION DRAIN TUBE
B300192-00	HOT WATER OUTLET TUBE REAR
B300193-00	STEAM OUTLET TUBE FRONT LEFT
B300194-00	STEAM OUTLET TUBE FRONT RIGHT
B30231	HEAT EXCHANGER OUTLET TUBE RIGHT
B30232	HEAT EXCHANGER OUTLET TUBE LEFT
B30237	HEAT EXCHANGER RETURN TUBE LEFT
B30238	HEAT EXCHANGER RETURN TUBE RIGHT
C300001-00	HOT WATER CONDUCT TUBE IN BOILER

ITEM NO.  
ITEM: BOILER HYDRALIC CIRCUIT

Pierro Silver 3 Group : (CE ETL)



ITEM NO.	Pierro Silver 3 Group : (CE ETL)
ITEM: BOILER HYDRALIC CIRCUIT	
A020023-00	ANTI-EDDY VALVE BASE
A020024-00	SHAFT
A020025-00	BRASS NUT
A02015A	AUT. WATER REFILL REDUCTION
A02018	BRASS CONNECTOR 1/4"X1/8"
A02022	ELBOW BRASS PT3/8*3/8
A02023	ELBOW BRASS 5/16*1/4
A02024	BRASS CONNECTOR PT1/4*1/2-20UNF*1/2-20UNF
A02029B	LEVEL PROBE BASE
A02030A	PROBE FIXED BOLT
A02047	BRASS CONNECTOR
A02068	BRASS FITTING PS/1/4*PS1/4*L42
A02069	BRASS FITTING PS/1/4*PS1/4*L33.5
A04006	HEATING ELEMENT 6000W (CE)
A050010-00	SAFETY VALVE
A05008	PRESSURE RELEASE TAP BULK UNIT PS1/4xPS1/4
A05012	FLOWMETER DOSER
A05013A	S.C.N.R.DOSER VALVE 1/2*1/2*1/2
A05020A	SOL. VALVE WATER REFILL ASSEMBLY 208~240V 60Hz (ETL)
A08002	PROBE ( SUS304 /3mm L132 )
A09010A	ELBOW BRASS CONNECTOR PF3/8 * PT1/8
A10008	NUT M8
A10030	HEX SCREM (M10*16)
A170008-00	SI O-RING
A170009-00	TEFLON WASHER
A170011-01	SI-GASKET ELEMENT
A17003A	NBR O RING
A180004-00	VALVE GASKET BRASS
A180005-00	VALVE GASKET BRASS
A23001	SPRING WASHER M8
A27002	PROBE FIXED SUPPORT
A28007	GROUP FILTER ST.STEEL D13.8*d10.5*11.5
B050006-00	ANTI-EDDY VALVE V.A.R.
B05003A	FLOW METER GAUGE
B080002-00	BOILER
B10002	LEVEL PROBE ASSEMBLY
B300011-00	FLOWMETER INLET TUBE
B300012-00	HEAT EXCHANGER INLET TUBE LEFT



B300013-00	HEAT EXCHANGER INLET TUBE MIDDLE
B300014-00	HEAT EXCHANGER INLET TUBE RIGHT
B300015-00	BOILER DRAIN TUBE FRONT
B300016-00	BOILER DRAINTUBE REAR
B300017-00	AUT.WATER REFILL TUBE REAR
B300019-00	WTAER LEVEL LOWER TUBE
B300022-00	EXPANSION DRAIN TUBE
B300023-00	AUT. WATER REFILL TUBE UPPER
B300047-00	HEAT EXCHANGER OUTLET TUBE LEFT
B300048-00	HEAT EXCHANGER OUTLET TUBE RIGHT
B300049-00	HEAT EXCHANGER OUTLET TUBE MIDDLE
B300050-00	HEAT EXCHANGER RETURN TUBE LEFT
B300051-00	HEAT EXCHANGER RETURN TUBE RIGHT
B300052-00	HEAT EXCHANGER RETURN TUBE MIDDLE
B300063-00	AUT.WATER REFILL TUBE MIDDLE
B300153-00	WATER LEVEL UPPER TUBE
B300157-00	STEAM PRESSURE GAUGE TUBE
B300195-00	HOT WATER OUTLET TUBE REAR
B300196-00	STEAM OUTLET TUBE FRONT LEFT
B300197-00	STEAM OUTLET TUBE FRONT RIGHT
C300001-00	HOT WATER CONDUCT TUBE IN BOILER